

Frame

NSN: **5975160034640**

PN (RN): **7013.100.01**

KČN: **0064742301391**

The frame is used for spring-mounted installation with four M8 screws into a vehicle. The frame is used for the installation of the RF13 transceiver and the DM13 mobile extension or RF13, DM13 and the RF13.1 battery pack. The frame secures mechanical resistance for patrol cars.