

# Frame

NSN: **5975160030959**

PN (RN): **7007.100.10**

KČN: **0064681901232**

The frame is used for spring-mounted installation with four M8 screws into a vehicle. The RF13 transceiver and the ZM13.1 or ZV13.1 amplifier are located on top of each other.