

# RC20 - Remote control unit

Type designation: **RC20**

PN (RN): **2312.100.01**

The remote control unit is intended for remote control of RF2050 mobile transceivers. It is recommended to be used wherever the transceiver size or location make it difficult for the operators to access its controls and indicator elements. The RC20 has the same controls as the transceiver and therefore the control method is identical. Operating information is displayed on an active OLED display, which ensures good readability in low light conditions. There are two ten-pin connectors at the top of the remote control panel - one is used to connect the RC20 panel with the REMOTE transceiver connector, the other connector is identical with the AF transceiver connector - it allows you to connect the handset. Vehicle installation using 4 M5 screws, spacing of holes (102 x 107) mm.

## Technické parametry

<b>Rozsah napájecího napětí</b>	7 V až 15 V
<b>Maximální příkon</b>	2 W
<b>Typ komunikačního protokolu</b>	PRC20
<b>Typ komunikační linky</b>	RS232 nebo RS485, nastavitelný radiostanicí
<b>Parametry asynchronní komunikační linky</b>	asynchronní, 57600 Bd
<b>Maximální délka propojovacího kabelu</b>	10 m (RS232) nebo 100 m (RS485)
<b>Rozměry</b>	120 mm x 147 mm x 44 mm [š x v x h]
<b>Hmotnost</b>	0,8 kg
<b>Rozsah pracovních teplot</b>	-30 °C až +70 °C
<b>Rozsah skladovacích teplot</b>	-40 °C až +70 °C

## Průvodní dokumentace

<b>Návod k obsluze RC20</b>	2312.010.01
<b>Zánamník</b>	6000002011
<b>Technický list</b>	6000002021

# Set

Type designation	PN (RN)	Name
RC20	2312.000.01	Remote control unit set